

OPERATING INSTRUCTIONS & HELPFUL TIPS

Compact Canvas/Panel Holder CT-PS-020 and Palette Box CT-PS-100

1 tripod setup



Tip: Adjust the rear (padded) leg of the tripod a few inches shorter than front legs. This will make the tripod more stable when you attach the supply/palette box.

2 attach quick release plate




- Thread the ballhead quick release plate to the mounting plate on the rear of the Compact Canvas/Panel Holder.
- Tighten with a screwdriver for a secure connection.

3 attach to ballhead




- Snap the quick release plate into the ballhead. Adjust the Compact Canvas/Panel Holder to the desired position. Tighten the ballhead handle.

4 adjust knobs for canvas size



- The Compact Canvas/Panel Holder can accommodate smaller and larger canvases and panels depending on the adjustable knob and bolt placement.

5 adjust canvas holder



- Loosen knob on rear of canvas holder.
- Raise the top canvas holder and place canvas or panel in place.
- Lower the canvas holder to secure canvas or panel and tighten knob.


* please note:



- By design the top canvas holder can rotate from side to side slightly. This is to ensure all 4 rubber bumpers make secure contact with the canvas.

IMPORTANT: Do not lift or move the tripod with the Palette Box attached to the legs. Doing so can cause the tripod legs to fold in and the Palette Box could fall. Always remove the palette box before adjusting or moving the tripod.

1 adjust palette box



- Loosen clamping black knobs. Adjust to the desired width and tighten knobs.

2 attach palette box



- With the palette box CLOSED, place the palette box on the front two legs of the Sienna Tripod.

Important Tip: Due to the weight of the palette box, it is helpful to adjust the rear leg a few inches shorter than front legs. This will make the tripod less front heavy and more stable.

3 using the palette box



- Unlatch and open.
- The palette box includes a tempered glass palette for paint mixing, removable and easy to clean. The two covers unfold into supply shelves with brush holders.

Other Sienna Accessories

Sienna Ultimate Plein Air Backpack

The Ultimate Plein Air Backpack was designed to hold the Sienna Tripod, Compact Canvas/Panel Holder, Palette Box and any of the Sienna Pochade boxes.

The backpack has three compartments with padded dividers; carries your solvent can, water bottle, and loads of other supplies. With padded back and shoulder straps, a sturdy carry handle and waist strap, it is the perfect backpack to carry your entire plein air studio.



Pastel Insert Grid

Watercolor Palette



sienna
plein air

Jack Richeson & Co., Inc.
557 Marcella St. Kimberly, WI 54136

1.800.233.2404
richesonart.com

